


OPEN-CUT METHOD



TRENCHLESS METHOD

NOTES:

1. LATERAL ABANDONMENT WORK LOCATED WITHIN CITY OF PITTSBURGH RIGHT-OF-WAY SHALL ADHERE TO THE DOMI'S RIGHT-OF-WAY PROCEDURES MANUAL.
2. LATERAL ABANDONMENT WORK ASSOCIATED WITH PRIVATE DEVELOPMENT SHALL ADHERE TO THE PWSA DEVELOPER'S MANUAL.
3. THE INSTALLATION OF A TRENCHLESS POINT REPAIR SHALL BE PROHIBITED.
4. THE ABILITY TO INSTALL A CURED-IN-PLACE PIPE IS NOT ALWAYS FEASIBLE AND DEPENDS ON THE SITE SPECIFIC FEATURES OF THE SEWER SEGMENT.



**Pittsburgh
Water & Sewer
Authority**

LATERAL ABANDONMENT

EDITED BY: LRC

CHECKED BY: RDH

APPROVED BY: BKK

STANDARD DETAIL ID

APPROVED DATE: 04/28/2023

NOT TO SCALE

SLT1